



Step-by-step installation instructions available on page 2 of this datasheet.

Drawing Legend

NO.	ITEM DESCRIPTION
1	Kilargo IFD-LL Intumescent Fire Damper Damper fitted in steel sleeve, with 4 self-drilling screws as tested and sealed at the perimeter with item 3.
2	Damper Casing 0.6mm or greater mild steel casing. The aperture shall be a minimum of 10mm and maximum 25mm filled with sealant (item 3).
3	Kilargo Intumescent Mastic Applied to the perimeter of Kilargo IFD-LL damper and the damper casing (both sides). Applied to the aperture gap between the damper casing and the wall, to the full depth or at least 30mm deep, controlled by a 16mm IBS rod.
4	Steel Angle 0.7mm (min) 40-mm x 40-mm x 25-mm galvanised steel angle steel angles fixed to damper casing with steel screws and anchors.
5	Rockwool Strip 13 mm Rockwool strip minimum density 70 kg/m3 as tested in FSV 1968.
6	Concrete and Masonry Walls For 60, 90 and 120 min. applications the concrete wall shall be min. 80mm, 100mm and 120mm and have the required FRL in accordance with AS 3600 For 60, 90 and 120 min. applications the masonry wall shall be min. 90mm, 110mm and 130mm and have the required FRL in accordance with AS 3700.
7	Gaps between damper casing and wall system firestopped with Kilargo intumescent mastic. Max Gap 25mm.
8	Casing length on either side of wall 0 - 150 mm max, fixed to duct.

,	Building element:	Masonry or Concrete
	Application:	Sleeve Mounted Single Sided Angle
	Maximum Size:	350mm Diameter
	FRL	-/120/120
	Test Reference No.	FC0-3344

WM5

System No.



Product Render: In-situ



Installation Instructions

- Ensure the wall penetration is sized and formed correctly for the IFD installation as detailed in the System Sheet
- 2. Position damper centrally in the penetration as per the System Drawing.
- Fire-stop any gaps between the casing & building element on both sides, with Kilargo Intumescent Mastic. Ensure fill depth corresponds with those detailed in the System Drawing. Backing material recommended for gaps above 10mm.
- Fasten supplied steel fixing angles to exterior of sleeve with steel self-drilling screws.
- 5. Fasten fixing angles to wall using appropriate masonry anchors.
- 6. Check and re apply any mastic if necessary, ensuring there is a full application as per the System Drawing

NOTE: Fixings are supplied by others.



System Notes

Kilargo Intumescent Fire Dampers shall be installed in accordance with this detail and in accordance with the requirements of AS1682.2 -Fire & Smoke Dampers. Installation & with note (but not limited to):

- If connecting ductwork to the installed damper casing, ensure that an appropriate AS1682.2 breakaway joint method is used -refer Clause 6.1(a)
- Ensure convenient access is provided for visual inspection and cleaning as necessary - refer Clause 6.1(d)
- 3. Ensure damper labels (product certification labels) are in a prominent position for easy identification during subsequent maintenance inspections refer Clause 7.2 (b)

,	Building element:	Masonry or Concrete	
	Application:	Sleeve Mounted Single Sided Angle	
	Maximum Size:	350mm Diameter	
	FRL	-/120/120	
	Test Reference No.	FC0-3344	

System No. WM5

