
FRL

Installation Instructions:

Ceiling Under Floor & Ceiling Under Roof Systems



Step 1	If ceiling is in framing stage, start at step 2 below. For existing fire rated ceilings, mark and cut out to suit internal IFD-CE1-LL plenum dimensions.
Step 2	Fix timber trimmers to ceiling joists to fully support weight of system as per system drawing.
Step 3	Fix IFD-CE1-LL box to framing with angles as per system drawing and attach ductwork to spigot
Step 4	Apply mastic to the inside of angles and fix to the inside of penetration & IFD-CE1 plenum as per system drawing.
Step 5	Fit register / diffuser as required.
Step 6	Ensure convenient access is provided for visual inspection and cleaning as necessary.
Step 7	Ensure product and certification labels are in a prominent position for easy identification during subsequent maintenance routines.

System Notes

- Grilles, diffuser, trimmers, angles and fixings are to be supplied by others.
- Kilargo Intumescent Fire Dampers shall be installed in accordance with this detail, including the use of Kilargo Intumescent Mastic (supplied separately) and in accordance with the requirements of AS1682.2
- Ensure convenient access is provided for visual inspection and cleaning as necessary
- Where the RISF is different between the fire rated floor/ceiling or roof/ceiling and the Kilargo IFD-CE1-LL, the lower RISF shall apply to both.

