

Length:

Description of contents

- Aluminium Housing (1)
- Silicone Gasket (2)
- Actuator Button (3)
- Smoke Fins (4)
- Bag containing
 - 2 x End caps
 - Fixing Screws
 - 1 x Striker Button
- Fitting Instructions

Tools required for installation

- Tape Measure
- Saw (Power or Hand)
- Screw Driver
- 2.5mm Drill Bit
- Drill (Power or Hand)
- Knife
- Pencil or Marker
- Router
- Long Series Router Bit

Cut back sizes:

Do not cut the seal shorter than the lengths indicated below or this will affect the normal operation of the internal mechanism.

- 380mm cuts to 275mm
- 600mm cuts to 380mm
- 820mm cuts to 600mm
- 920mm cuts to 820mm
- 1070mm cuts to 920mm
- 1220mm cuts to 1070mm

Installation detail: Automatic door bottom seal

- Step 1** Remove the seal from the packaging .
- Step 2** Remove the door from its hinges, lay on it's side and firmly restrain. (If the door bottom is already grooved to suit the seal dimensions, go to Step 5.)
- Step 3** Measure and mark the seal position on the bottom edge of the door. For optimum operation, the seal should be positioned on the centre line of the door.
- Step 4** Fit a suitable cutter to the router and set guide. Machine a 13mm wide by 24mm deep groove along the bottom of the door. See Figure 1.
- Step 5** Clear chips and dust from groove, check width and depth.
- Step 6** *Warning: Check maximum cut back lengths on the table provided.* Measure the door width. Pull back the gasket from the opposite end to the actuator button and using a power saw/ hacksaw, cut the aluminium sections to the measured length. Remove cutting swarf. Push the gasket back into position and cut to length with a sharp knife.
- Step 7** Position the seal in the groove and mark fixing hole positions on the bottom edge. Ensure that the actuator button is on the hinge side of the door.
- Step 8** Drill pilot holes and then screw fix seal into position. See Fig 2. Fit end caps.
- Step 9** When the door leaf is re-fitted open and close the door observing the operation of the seal. Adjust accordingly by winding the actuator button clockwise to reduce movement and anticlockwise to increase the seal movement. (For timber frames, fix the striker button to the frame opposite the operating button.)
Note: For optimum results the seal should be adjusted so that the seals silicone gasket touches the sill in the final closing moment of the door.

We recommend IS8005si automatic door bottom seal be used together with a Kilargo IS7000 series perimeter seal and, if required a 4000 series threshold plate.

Note

Recommendations as to methods for use of materials and construction details are based on the experience and knowledge of Kilargo and are given in good faith as a general guide and service to designers, contractors and manufacturers.

Kilargo reserves the right to make alterations or delete any installation detail without prior notice.

Important

Ensure that the installation of this product does not impede the opening or closing of the door. It is recommended to check the adjustment of the door seal periodically to ensure the door assembly to which it is fitted, closes and latches properly.




Figure 1




Figure 2

Other Integrity™ Architectural Seals include:

- Door Perimeter Seals
- Door Bottom Seals
- Automatic Door Bottom Seals
- Threshold Plates
- Brush Seals
- Magnetic Seals

Contact your nearest Kilargo office for further details.