


Installation Instructions

Single cell units in steel casing penetrating 75SW Hebel wall

- 1. Position the damper as detailed in the System Drawing.
- **2.** Position & fasten mounting angles, using screws & anchors as detailed in the System Drawing.
- 3. Firestop any gaps between the damper & building element with Kilargo Intumescent Mastic (supplied separately). Ensure fill depth corresponds with those detailed in the System Drawing. Note:
 - A maximum perimeter clearance of 25mm applies.
- **4.** If connecting ductwork, ensure that an appropriate AS1682.2 compliant breakaway joint method is used.
- **5.** Ensure convenient access is provided for visual inspection and cleaning as necessary.
- **6.** Ensure product and certification labels are in a prominent position for easy identification during subsequent maintenance inspections.

Notes

- 1. Product must be fitted in accordance with this detail, including the use of Kilargo Intumescent Mastic to ensure compliance with Kilargo Fire Test Approval detailed.
- **2.** Steel casing, angles, fixing screws and anchors are to be supplied by others.



Hebel 75SW
Steel casing tight to underside of slab with 3 angles
300mm x 300mm
-/120/-
CSIRO FC02495
WH7