


Installation Instructions

IFD44 mounted in Vermiculux panel with FR Board

1. Position damper centrally in penetration aperture as per System Drawing.
2. Fire-stop any gaps between the damper & Vermiculux panel with Kilargo Intumescent Mastic (supplied separately). Ensure fill depth corresponds with those detailed in the System Drawing.
3. Fasten Z angles to damper with steel self-drilling screws.
4. Fix Z angles to wall using 10g x 40mm coarse thread screws (supplied by others).
5. If connecting ductwork to the installed damper casing, ensure that an appropriate AS1682.2 compliant breakaway joint method is used.
6. Ensure product and certification labels are in a prominent position for easy identification during subsequent maintenance inspections.
7. Ensure convenient access is provided for visual inspection and cleaning as necessary.

Notes

1. Product must be fitted in accordance with this detail, including the use of Kilargo Intumescent Mastic to ensure compliance with Kilargo Fire Test Approval detailed.
2. Fixing screws, angles and anchors are to be supplied by others.



| | |
|--------------------|---|
| Building Element | Vermiculux |
| Application | Mounted in 60mm thick Vermiculux board with fire resistant cladding |
| Maximum Size | 800mm x 800mm |
| FRL | -/120/- |
| Test Reference No. | BRANZ FAR3404 |

System No. **WV3**